



Installing Pontoon Furniture

Congratulations on your purchase on new pontoon boat seats from Veada. Follow these simple instructions for the installation of your Veada pontoon furniture. For best results, use all stainless steel hardware for installation.

1. With a clear deck, place the new pontoon boat seats in place within your pontoon railing. Make sure all carpet and decking is in proper shape.

2. To create a snug fit between the pontoon furniture, bolt each separate piece on pontoon furniture together, eliminating any gaps between seats. Situate the furniture in place and pre-drill (2) 5/16" holes – with (1) hole located 5" above the base of the seat and (1) hole located at the same height, 5" away horizontally. Insert a 1/4" x 20 x 1" bolt, two washers and nut per hole. Tighten until the gap between the pontoon furniture is reduced.



3. With the pontoon furniture situated on your pontoon deck, use bolts or lag screws for installation to the pontoon deck.

(Recommended) For bolt installation

- a. Pre-drill (1) 5/16" hole in each corner or (4) per bench. After pre-drilling each hole, drop a bolt in place to help with the alignment of the holes. Insert (1) 1/4" x 20 x 2 1/2" bolt, two washers and one nylock nut per hole. Tighten securely. For added security, use two nylock nuts to prevent loss of nuts.

For lag screw installation

- a. Install (1) #12, 1 1/2" lag screw and washer in each corner or (4) per bench.



Congratulations on the installation of your new pontoon furniture. Happy boating!