

Single Wide Helm Seat Installation

Mounting your single wide helm seat is easy. Use stainless steel hardware and follow these simple instructions.

1. Most of Veada single wide [helm seats](#) will mount to a pedestal top with a 5"x5" or 5"x12" bolt pattern. Reclining helm seats will mount to 5"x12" bolt patterns only.



2. Your helm seat base will come with multiple 1/4" x 20 t-nuts pre-embedded in the rotocast plastic base. These t-nut locations will be at 5"x5" and 5"x12", matching most boat pedestals. As an automatic option for high torque applications, Veada includes a pre-mounted reinforcement board. Veada recommends using this board with 5"x5" pedestals.
3. If able, remove your pedestal top from the post. With the helm seat flipped upside down, place the pedestal top on the base of the helm seat. Using the included 4 - 1/4" x 20 stainless steel bolts and washers, start each bolt in the corresponding hole by hand. Continue tightening the bolt with a phillips screwdriver. Do not use power tools to tighten.
4. With your pedestal top mounted on the helm seat base, flip the seat over and place it back on the pedestal post.



3/4" Reinforcement Board Included
 As Automatic Option

You've completed the installation. Happy Boating!